


## INSTRUCTION


## PROGRAMMING THE REMOTE CONTROL







Release the button when the garage door opener lights blink **or** two clicks are heard. If programming to other products, press the button a second time to activate the product.



Compatible with Green Learn Button Only